


## **OPERATION & SERVICE MANUAL**



Models: 06-4035CSeries 06-4035C0500, 06-4035C0800, 06-4035C3300, 06-4035C3600 Fluid Service Unit



10/2017 - Rev. 02

**Includes Illustrated Parts List** 

Phone: (419) 866-6301 | 800-426-6301

Web: www.tronair.com

Email: sales@tronair.com

 REVISION
 DATE
 TEXT AFFECTED

 OR
 08/2000
 Original release


 01
 11/2014
 Added 06-4035C3300

 02
 10/2017
 Modified Appendices



#### **TABLE OF CONTENTS**

		<u></u>	AGE
1.0	PROD	DUCT INFORMATION	1
	1.1	DESCRIPTION	1
	1.2	MODEL & SERIAL NUMBER	1
	1.3	MANUFACTURER	1
	1.4	SPECIFICATIONS	
	1.5	FEATURES	
2.0	PREP	PARATION FOR USE	1
3.0		NING	
	3.1	TRAINING REQUIREMENTS	1
	3.2	TRAINING PROGRAM	
	3.3	OPERATOR TRAINING	
4.0	OPER	RATION	
	4.1	UNIT USE	2
	4.2	COMPONENT TESTING	2
5.0	PROV	/ISION OF SPARES	2
	5.1	SOURCE OF SPARE PARTS	2
	5.2	RECOMMENDED SPARE PARTS LISTS	2
6.0	IN SE	RVICE SUPPORT	
7.0		RANTEES/LIMITATION OF LIABILITY	
8.0		NDICES	





This product can not be modified without the written approval of Tronair, Inc. Any modifications done without written approval voids all warranties and releases Tronair, Inc., its suppliers, distributors, employees, or financial institutions from any liability from consequences that may occur. Only Tronair OEM replacement parts shall be used.

#### 1.0 PRODUCT INFORMATION

#### 1.1 DESCRIPTION

The Tronair Fluid Service Unit is a compact unit designed to provide a source of clean, pressurized fluid for filling reservoirs, bleeding brakes and other maintenance functions.

#### 1.2 MODEL & SERIAL NUMBER

Reference nameplate on unit

#### 1.3 MANUFACTURER

TRONAIR, Inc. Telephone: (419) 866-6301 or 800-426-6301

 1740 Eber Road
 Fax: (419) 867-0634

 Holland, Ohio 43528-9794 USA
 E-mail: sales@tronair.com

 Website: www.tronair.com

#### 1.4 SPECIFICATIONS

Tank Capacity: 8 gallonsMaximum Pressure: 5000 PSIG

• Fluid:

06-4035C0500 ..........MIL-PFR-5606/MIL-PFR-83282 06-4035C0800 ..........MIL-L-23699, MIL-PRF-87257

06-4035C3300 ...... HyJet V

06-4035C3600 ...... Phosphate Ester

Filtration: 2 Micron Weight: 65 lbs

#### 1.5 FEATURES

- 15 foot hose
- Pressure gauge
- Shut-off valve for component testing
- 5,000 PSI pump provides high pressure capability

#### 2.0 PREPARATION FOR USE

The unit is shipped fully assembled and only the following steps are required to make the unit operational:

- 1. Service Reservoir: Fill reservoir with appropriate clean fluid
- 2. Adjust handle height to suit

#### Remove Air From Unit System By:

- 1. Close manual pump release screw located at lower right corner of pump base block
- 2. Open shut-off valve adjacent to pressure gauge
- 3. Flow fluid by actuating manual pump

#### 3.0 TRAINING

#### 3.1 TRAINING REQUIREMENTS

The employer of the operator is responsible for providing a training program sufficient for the safe operation of the unit.


#### 3.2 TRAINING PROGRAM

The employer provided operator training program should cover safety procedures concerning use of the unit in and around the intended aircraft at the intended aircraft servicing location.

#### 3.3 OPERATOR TRAINING

The operator training should provide the required training for safe operation of the unit.

NOTE: Maintenance and Trouble Shooting are to be performed by a skilled and trained technician.





#### 4.0 OPERATION

#### 4.1 UNIT USE

#### Follow the steps below:

- 1. Securely attach hose to the aircraft
- 2. Close pump release screw
- 3. Open shut-off valve
- 4. Transfer fluid by actuating the manual pump

#### When service has been completed:

- 1. Open pump release screw to relieve pressure
- 2. Disconnect hose from aircraft
- 3. Install hose end dust plug

#### 4.2 COMPONENT TESTING

A shut-off valve had been provided to assure no back flow of fluid. Therefore, shut-off valve is to be closed after the required pressure has built up in the system.

Pressure is relieved by opening this shut-off valve and the pump release screw.

#### 5.0 PROVISION OF SPARES

#### 5.1 SOURCE OF SPARE PARTS

Spare parts may be obtained from the manufacturer:

**TRONAIR**, Inc. Telephone: (419) 866-6301 or 800-426-6301

1740 Eber Road Fax: (419) 867-0634
Holland, Ohio 43528-9794 USA E-mail: sales@tronair.com
Website: www.tronair.com

#### 5.2 RECOMMENDED SPARE PARTS LISTS

Reference the following page(s) for Replacement Parts and Kits available.

#### 6.0 IN SERVICE SUPPORT

Contact Tronair, Inc. for technical services and information. See Section 1.3 – Manufacturer.

#### 7.0 GUARANTEES/LIMITATION OF LIABILITY

Tronair products are warranted to be free of manufacturing or material defects for a period of one year after shipment to the original customer. This is solely limited to the repair or replacement of defective components. This warranty does not cover the following items:

- a) Parts required for normal maintenance
- b) Parts covered by a component manufacturers warranty
- c) Replacement parts have a 90-day warranty from date of shipment

If you have a problem that may require service, contact Tronair immediately. Do not attempt to repair or disassemble a product without first contacting Tronair, any action may affect warranty coverage. When you contact Tronair be prepared to provide the following information:

- a) Product Model Number
- b) Product Serial Number
- c) Description of the problem

If warranty coverage is approved, either replacement parts will be sent or the product will have to be returned to Tronair for repairs. If the product is to be returned, a Return Material Authorization (RMA) number will be issued for reference purposes on any shipping documents. Failure to obtain a RMA in advance of returning an item will result in a service fee. A decision on the extent of warranty coverage on returned products is reserved pending inspection at Tronair. Any shipments to Tronair must be shipped freight prepaid. Freight costs on shipments to customers will be paid by Tronair on any warranty claims only. Any unauthorized modification of the Tronair products or use of the Tronair products in violation of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied.


The obligations of Tronair expressly stated herein are in lieu of all other warranties or conditions expressed or implied. Any unauthorized modification of the Tronair products or use of the Tronair products in violations of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied and Tronair disclaims any and all liability for injury (WITHOUT LIMITATION and including DEATH), loss or damage arising from or relating to such misuse.

#### 8.0 APPENDICES

APPENDIX I Hand Pump - HC-2557
APPENDIX II Declaration Of Conformity



Parts List
When ordering replacement parts/kits, please specify model, serial number and color of your unit.



Item	Part Number	Description	Qty
1	U-1001-01	Wheel, 8" Diameter	1
2	Z-4182-01	Weldment, HSU Frame	1
3	G-1100-107006	Bolt, Hex Head GR 5, % - 16 x 1/4 Long	Ref
4	G-1202-1075	ESN, 3/8 - 24	1
5	G-1250-1070N	Flatwasher, % Narrow	2
6	G-1100-107524	Bolt, Hex Head GR 5, % - 24 x 2 ½ Long	1
7	Z-1083-01	Weldment, handle	1
8	H-11443	Cap, End	2
9	V-1779	Label, Serial Number (CE)	1
10	V-1001	Label, Made In USA	1
11	G-1100-107010	Bolt, Hex Head GR 5, % - 16 x 1 Long	Ref
12	G-1251-1070R	Lockwasher, % Regular	Ref
13	H-1009-01	Handle, Pump	1
14	G-1250-1090N	Flatwasher, ½ Narrow	4



#### **Parts List**

When ordering replacement parts/kits, please specify model, serial number and color of your unit.

Item	Part Number	Description	Qty
15	G-1203-1095	ESN, ½ - 20	2
19	V-1198	Label, Tronair	1
21	V-1431	Tag, Flush System	1

#### THE FOLLOWING PARTS ARE FLUID SPECIFIC

#### Parts List - 06-4035C0500

MIL-PRF-5606/MIL-PRF-83282

Item	Part Number	Description	Qty
16	Z-7737-01	Assembly, Hydraulic	1
17	V-1380	Label, Fluid	1
20	V-1526	Label, Filter Element	1
22	TF-1043-01*180	Assembly, Hose ¼ x 180 Long	1
Not Shown	HC-2765	Hand Pump	1

### Parts List - 06-4035C0800

MIL-L-23699, MIL-PRF-87257

Item	Part Number	Description	Qty
16	Z-7737-03	Assembly, Hydraulic	1
17	V-1035	Label, Fluid	1
20	V-1526	Label, Filter Element	1
22	TF-1038-14*180	Assembly, Hose ¼ x 180 Long	1
Not Shown	HC-2558	Hand Pump	1

# Parts List - 06-4035C3300

HyJet V


Item	Part Number	Description	Qty
16	Z-7737-02	Assembly, Hydraulic	1
17	V-2582	Label, Fluid	1
20	V-1460	Label, Filter Element	1
22	TF-1041-05*180	Assembly, Hose ¼ x 180 Long	1
Not Shown	HC-2557	Hand Pump	1

### Parts List - 06-4035C3600

**Phosphate Ester** 

Item	Part Number	Description	Qty
16	Z-7737-02	Assembly, Hydraulic	1
17	V-1100	Label, Fluid	1
20	V-1460	Label, Filter Element	1
22	TF-1041-05*180	Assembly, Hose ¼ x 180 Long	1
Not Shown	HC-2557	Hand Pump	1





# Parts List - 06-4035C0500, 06-4035C0800 MIL-PRF-5606/MIL-PRF-83282, MIL-L-23699/MIL-PRF-87257

Item	Part Number	Description	Qty
	HC-1101-01	Assembly, Valve (Complete Component)	1
2	HC-1082	Handle, Valve	1
3	HC-2000-011	O-ring	1


## Parts List - 06-4035C3300, 06-4035C3600

HyJet V, Phosphate Éster

Item	Part Number	Description	Qty
	HC-1101-02	Assembly, Valve (Complete Component)	1
2	HC-1082	Handle, Valve	1
3	HC-2006-011	O-ring	1




HC-1675 Pressure Filter Assembly 06-4035C0500, 06-4035C0800 MIL-PRF-5606/MIL-PRF-83282, MIL-L-23699/MIL-PRF-87257



Item	Part Number	Description	Qty
1	HC-1675	Assembly, Pressure Filter	1
4	K-2318	Kit, Filter Element Replacement; consists of:	
2	HC-2000-235	O-ring, Series 2	1
3	HC-1676	Element, Filter	1



# HC-1675 Pressure Filter Assembly 06-4035C3300, 06-4035C3600 HyJet V, Phosphate Ester



Item	Part Number	Description	Qty
1	HC-1581	Assembly, Pressure Filter	1
4	K-2131	Kit, Filter Element Replacement; consists of:	
2	HC-2006-235	O-ring, Series 2	1
3	HC-1587	Element, Filter	1



# **APPENDIX I**

HC-2557
Phosphate Ester Hand Pump
Parts List



# HC-2557 Hydraulic Hand Pump

\*\*\*

# Parts List With Illustrations

01/2012 - Rev. 01

When ordering Replacement Parts/Kits, please specify Model, Color and Serial Number of your Unit.

Phone: (419) 866-6301 | 800-426-6301

Web: www.tronair.com

Email: sales@tronair.com



This product can not be modified without the written approval of Tronair, Inc. Any modifications done without written approval voids all warranties and releases Tronair, Inc., its suppliers, distributors, employees, or financial institutions from any liability from consequences that may occur. Only Tronair OEM replacement parts shall be used.


# Parts List This pump is compatible with Phosphate Ester Hydraulic Fluids.

Reference Parts List Illustration on following page.

Item	Part Number	Description	Qty
1	583-120	Plug	1
2	09-ADDF-04-20 x 56	Tie Rod	4
3	582-120	Flange, Retaining	3
4	563-121	Tube	4
5	562-125	Piston - High Pressure	5
8	564-120	Retainer Plate	1
9	560-120	Valve Body	1
12	577-120	Spring, Outlet - Low Pressure	1
15	CXD-000003-001	Body	1
16	CXD-110028-003	Relief Assembly, 5000	1
18	505-001	Plug, Valve Body	3
21	514-034	Spring, Outlet Check	1
22	517-000	Ball, Outlet Check	4
24	570-120	Spring - Bypass	1
25	571-121	Piston - Bypass	1
26	569-120	Ball - Bypass	1
28	566-125	Piston - Low Pressure	1
33	516-120	Spring - High Pressure Inlet	1
34	573-120	Spring – Intake Low Pressure	1
35	CXD-000003-002	Screw, Release	1
36	519-0000	Roll Pin	1
37	CXD-000003-004	Release Screw Retainer	1
39	09-AYDF-06-16X03	Lock Screw	1
40	516-120	Spring, Ball Check	1
	SRK-PL-000	Assembly; consists of:	
27	508-000	Pivot	1
29	512-000	Strap	2
30	510-001	Pin Linkage Assembly	2
31	531-000	Clevis Pin Assembly	1
32	509-C00	Handle Bracket	1
		Kit; consists of:	
6		High Pressure Piston Seal	5
7		O-Ring, EPR	1
10		O-Ring, EPR	1
11		O-Ring, EPR	1
13		O-Ring, EPR	4
14		Back-Up Teflon	4
17		O-Ring, EPR	1
19		Back-Up Split	1
20		O-Ring, EPR	1
23		O-Ring, EPR	1
38		O-Ring, EPR	1



# **Parts List Illustration**





# **APPENDIX II**

**Declaration of Conformity** 



## **DECLARATION of CONFORMITY**

The design, development and manufacture is in accordance with European Community guidelines

06-4035C0500 06-4035C0800 06-4035C3300 06-4035C3600

Relevant provisions complied with by the machinery: 2006/42/EC

Identification of person empowered to sign on behalf of the Manufacturer:

Quality Assurance Representative

Phone: (419) 866-6301 | 800-426-6301

Web: www.tronair.com

Email: sales@tronair.com