

### K-3068 - PW535 Engine Adapter

This product can not be modified without the written approval of Tronair, Inc. Any modifications done without written approval voids all warranties and releases Tronair, Inc., its suppliers, distributors, employees, or financial institutions from any liability from consequences that may occur.



This Pratt Whitney PW-535 Engine Support Kit is to be used with 08-2030-0000 engine stand. The engine stand has multiple adjustments to accommodate the installation of various engines using specific engine adapter kits.

#### **ENGINE INSTALLATION INSTRUCTIONS:**

- 1. With the engine hung from the engine sling, remove the existing air frame mounts from the engine.
- 2. Attach the engine mounting pads (Z-3792) to the engine mounting locations on the front of the engine and attach the rear mounting adapter (Z-4332) to the rear attach point on the engine. (See *Figure 1*.)
- 3. Position the front support beam 26~5/16 inches from the rear support post. (See Figure 1).
- 4. Position the height of the rear support up 11~5/32 inches. (See Figure 1).
- 5. Position engine into the engine stand and attach rear adapter to engine stand.
- 6. Adjust final location of the front support beam and attach the front engine mounting pads to the engine stand.
- 7. Tighten the lock out screws on the front support beam.
- 8. The engine sling can now be removed for engine service.
- 9. Reverse steps 2-8 to remove the engine from the stand.




FIGURE 1

Phone: (419) 866-6301 | 800-426-6301 Web: www.tronair.com

Email: sales@tronair.com



#### **GUARANTEES/LIMITATION OF LIABILITY**

Tronair products are warranted to be free of manufacturing or material defects for a period of one year after shipment to the original customer. This is solely limited to the repair or replacement of defective components. This warranty does not cover the following items:

- a) Parts required for normal maintenance
- b) Parts covered by a component manufacturers warranty
- c) Replacement parts have a 90-day warranty from date of shipment

If you have a problem that may require service, contact Tronair immediately. Do not attempt to repair or disassemble a product without first contacting Tronair, any action may affect warranty coverage. When you contact Tronair be prepared to provide the following information:

- a) Product Model Number
- b) Product Serial Number
- c) Description of the problem


If warranty coverage is approved, either replacement parts will be sent or the product will have to be returned to Tronair for repairs. If the product is to be returned, a Return Material Authorization (RMA) number will be issued for reference purposes on any shipping documents. Failure to obtain a RMA in advance of returning an item will result in a service fee. A decision on the extent of warranty coverage on returned products is reserved pending inspection at Tronair. Any shipments to Tronair must be shipped freight prepaid. Freight costs on shipments to customers will be paid by Tronair on any warranty claims only. Any unauthorized modification of the Tronair products or use of the Tronair products in violation of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied.

The obligations of Tronair expressly stated herein are in lieu of all other warranties or conditions expressed or implied. Any unauthorized modification of the Tronair products or use of the Tronair products in violations of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied and Tronair disclaims any and all liability for injury (WITHOUT LIMITATION and including DEATH), loss or damage arising from or relating to such misuse.

Phone: (419) 866-6301 | 800-426-6301 Web: www.tronair.com Email: sales@tronair.com



Parts List
When ordering Replacement Parts/Kits, please specify Model, Color and Serial Number of your Unit



| Item | Part Number | Description                                 | Qty |
|------|-------------|---|-----|
| 1    | Z-3791      | Weldment, PW535 Mount                       | 1   |
| 2    | G-1455      | Bolt, 7/16 -20 Modified                     | 4   |
| 3    | G-1255-08   | Washer, 7/16" diameter                      | 4   |
| 4    | G-1351-04   | Rivet, 1/8 Open-End Steel                   | 1   |
| 5    | H-1026*07.0 | Assembly, Lanyard                           | 2   |
| 6    | G-1310-0520 | Pin, Ball Lok-T, 5/16" diameter x 2.0" long | 2   |
| 7    | Z-4331      | Weldment, PW535 Rear Adapter                | 1   |

Phone: (419) 866-6301 | 800-426-6301 Web: www.tronair.com Email: sales@tronair.com



### **DECLARATION of CONFORMITY**

The design, development and manufacture is in accordance with European Community guidelines

K-3068 Engine Adapter PW535

Relevant draft complied with by the machinery: EN ISO 12100-1

Relevant standards complied with by the machinery: EN ISO 12100-1 EN 1915-1:2001 (5.20)

Identification of person empowered to sign on behalf of the Manufacturer:

Quality Assurance Representative

Phone: (419) 866-6301 | 800-426-6301

Web: www.tronair.com

Email: sales@tronair.com



# The Tronair Family of Ground Support Equipment and cloud based EBis GSE Fleet Management



## The premier global supplier of ground support equipment



# The Tronair Family of GSE Product Lines

#### UNPARALLELED RANGE OF PRODUCTS FOR BUSINESS, COMMERCIAL AND MILITARY AIRCRAFT

#### **LIFTING & SHORING (ATA-7)**

Hydraulic Tripod Jacks Axle Jacks Jack Test Equipment Stabilizing Stands & Alarms Aircraft Recovery Dollies

#### **LEVELING & WEIGHING (ATA-8)**

Aircraft Weigh Equipment

#### **TOWING AND TAXIING (ATA-9)**

**Towbar Systems** Tow Vehicles & Tractors

#### **PARKING & MOORING (ATA-10)**

Chocks & Covers

#### **SERVICING (ATA-12)**

Multi-Purpose Carts Hydraulic & Engine Oil Servicing & Test Equipment Lavatory Servicing Carts Potable Water Transport Carts Oxygen & Nitrogen Carts Oxygen & Nitrogen Boosters

#### **AIR CONDITIONING (ATA-21)**

Air Conditioning Equipment Coolant System Fill/Drain Carts Cabin Pressurization Test Units

#### **ELECTRICAL (ATA-24)**

**Ground Power Units** Battery Charger/Analyzer

#### FUEL (ATA-28)

**Fuel Transfer Cart Fuel Tools** 

#### **HYDRAULIC POWER (ATA-29)**

Hydraulic Power Units Ram Air Turbine (RAT) Hydraulic Coupling Hose Adaptors

#### **ICE & RAIN PROTECTION (ATA-30)**

**Deicer Carts** 

#### AIRCRAFT TOOLING

Designed to your Specifications

#### **LANDING GEAR (ATA-32)**

Beadbreakers Dollies - Wheel & Brake Service Tools Strut Service Carts Regulators, Adaptors, Connectors & Gauges

#### **FUSELAGE (ATA-53)**

Lifts. Cranes & Hoists Maintenance Platforms Access Stands **Docking Systems** 

#### **PROPELLERS (ATA-61)**

Propeller Stands/Slings/Tools

#### **POWER PLANT (ATA-71)**

**Engine Compressor Washers** Engine Hoists, Slings & Stands

#### **CLOUD BASED FLEET MGT.**

Manage your Repair Station, Multi Location Jet Center or **Small Operation** 



www.tronair.com

www.columbusjack.com | www.daeind.com | www.datcomedia.com | www.eagletugs.com | www.malabar.com

Sales Offices: USA • Asia/China • Australia/New Zealand/Singapore • Europe/Middle East/Africa

Tronair, Inc. • 1 Air Cargo Pkwy East • Swanton, OH 43558, USA Phone: 419-866-6301 | Toll Free: 1-800-426-6301 | Email: sales@tronair.com