


# **OPERATION & SERVICE MANUAL**



Model: 10D4036-0010 Lavatory Service Unit



06/2009 - Rev. 02

REVISION DATE TEXT AFFECTED

01 02/2006 Modified cover illustration
Modified illustrations and parts list

02 06/2009 Revised pumps



### **TABLE OF CONTENTS**

	PAGE
1.0	GENERAL DESCRIPTION1
2.0	TECHNICAL SPECIFICATIONS
2.1	FILL (FRESH) SYSTEM
2.2	DUMP SYSTEM.
2.3	MECHANICAL
2.4	FIELD INSTALLED KITS1
3.0	PREPARATION FOR USE
4.0	OPERATING INSTRUCTIONS
5.0	MAINTENANCE
6.0	TROUBLE SHOOTING
6.1	FAILURE TO PUMP LIQUID
6.2	DUMP PUMP FAILS DURING USE
7.0	GUARANTEES/LIMITATION OF LIABILITY
8.0	APPENDICES



Model: 10D4036-0010 **Lavatory Service Unit** 

This product can not be modified without the written approval of Tronair, Inc. Any modifications done without written approval voids all warranties and releases Tronair, Inc., its suppliers, distributors, employees, or financial institutions from any liability from consequences that may occur. Only Tronair OEM replacement parts shall be used.

### **GENERAL DESCRIPTION**

The Tronair Model 10D4036-0010 Lavatory Service Unit (LSU) provides a clean, sanitary means of servicing the aircraft lavatory system and transporting the waste fluid to the dump station.

Some important features are:

- Easily maneuverable with towbar
- Drain back system on fill hose to prevent fluid spillage
- Storage tubes for storage of fill and dump hoses
- Heavy duty fill and dump pumps
- Fill and dump tanks made of non-corroding HD polyethylene material with UV inhibitor
- Permanent connection of dump hose to dump tank
- 3 and 4 inch dump tank flanges

### **TECHNICAL SPECIFICATIONS**

Dimensions: 54 inches long

36 inches wide

29 inches high

Weight: 280 pounds

#### 2.1 FILL (FRESH) SYSTEM

- 15 gallon tank capacity; HD Polyethylene
- One gallon per six strokes fill pump
- 3 inch tank fill port with cover
- 8 foot fill hose
- 20 psi max fill pump pressure

#### 2.2 **DUMP SYSTEM**

- 31 gallon tank capacity; HD Polyethylene
- 30 gpm manual diaphragm pump
- 6 inch tank clean out port with cover
- 3 and 4 inch aluminum tank flanges for aircraft dump hose connection
- 10 foot dump tank hose

#### 2.3 **MECHANICAL**

- 8 inch pneumatic tires; 50 psi tire pressure maximum
- Roller bearings in wheels; zerk fittings
- 10 mph maximum towing speed

#### 2.4 FIELD INSTALLED KITS

- Kit, Dump hose SD 330/360 K-1036:
- K-2410: Kit. Fill Connector
- K-2412: Kit, Dump Connector with five foot hose Kit, Dump Connector; mates with K-2412 K-2029:
- Kit, Dump Connector K-2030:
- K-3606 Kit, Hose Cap (Dump Hose)

#### PREPARATION FOR USE 3.0

This Lavatory Service Unit has been thoroughly inspected and tested prior to packaging and shipment. The unit is shipped completely assembled and is ready to use.

You are requested to generally check over the unit to assure the tightness of all nuts, bolts and screws that may have loosened during shipment. Bolts and elastic stopnuts should be tightened to a torque not to exceed industry standards for Grade '5' bolts.

Tire pressure should not exceed 50 psi.



Model: 10D4036-0010 Lavatory Service Unit

#### 4.0 OPERATING INSTRUCTIONS

- 1. Open access panel on aircraft. Remove drain and fill coupling caps.
- Connect the dump hose assembly to the aircraft drain coupling and fill hose assembly to mating aircraft coupling.
- Follow aircraft manufacturer's instructions to drain sewage from aircraft into dump tank.
- 4. To flush aircraft toilet, the three-way ball valve on the fill pump must have its handle toward the hand pump as shown in *Figure 1*. Follow aircraft manufacturer's requirements for flushing. Six strokes of fill pump will deliver one gallon of fluid.
- 5. After flushing, rotate three-way ball valve handle in direction shown. This allows for fill hose to be partially drained prior to disconnecting from aircraft.
- 6. Remove dump and fill hoses from aircraft and stow.
- Following aircraft manufacturer's instructions, replace coupling caps on aircraft fittings. Close the access panel securely.
- 8. Pump sewage into approved disposal system. Refill fill tank as required. Lavatory Service Unit is now ready for reuse.




FIGURE 1

### 5.0 MAINTENANCE

- 1. Lubricate wheel bearings with multi-purpose grease a minimum of every six months.
- 2. Lubricate front caster swivel plate bearings with multi-purpose grease every six months minimum.
- 3. Periodically check for leaks at hose connections and tighten hose clamps as required.
- 4. Regularly wash tanks and hoses with a mild detergent according to local procedures and regulations.

### 6.0 TROUBLE SHOOTING

If fill pump fails during use, refer to illustration of WC-1053 Pump Assembly and disassemble for inspection of pump internals. Clean inside of pump. Replace any damaged parts.

### 6.1 FAILURE TO PUMP LIQUID

- 1. Pump Will Not Prime: Possible Clogged Suction; check that suction tubes are clear.
- 2. Not Enough Flow: Check suction and discharge hoses for clogging or pinching. Verify that nozzle is not clogged.

### 6.2 DUMP PUMP FAILS DURING USE

Refer to Illustration of WC-1054 Discharge Pump Assembly and disassemble for inspection of pump internals. Clean inside of pump. Replace any damaged parts.

### 7.0 GUARANTEES/LIMITATION OF LIABILITY

Tronair products are warranted to be free of manufacturing or material defects for a period of one year after shipment to the original customer. This is solely limited to the repair or replacement of defective components. This warranty does not cover the following items:

- a) Parts required for normal maintenance
- b) Parts covered by a component manufacturers warranty
- c) Replacement parts have a 90-day warranty from date of shipment

If you have a problem that may require service, contact Tronair immediately. Do not attempt to repair or disassemble a product without first contacting Tronair, any action may affect warranty coverage. When you contact Tronair be prepared to provide the following information:

- a) Product Model Number
- b) Product Serial Number
- c) Description of the problem


If warranty coverage is approved, either replacement parts will be sent or the product will have to be returned to Tronair for repairs. If the product is to be returned, a Return Material Authorization (RMA) number will be issued for reference purposes on any shipping documents. Failure to obtain a RMA in advance of returning an item will result in a service fee. A decision on the extent of warranty coverage on returned products is reserved pending inspection at Tronair. Any shipments to Tronair must be shipped freight prepaid. Freight costs on shipments to customers will be paid by Tronair on any warranty claims only. Any unauthorized modification of the Tronair products or use of the Tronair products in violation of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied.

The obligations of Tronair expressly stated herein are in lieu of all other warranties or conditions expressed or implied. Any unauthorized modification of the Tronair products or use of the Tronair products in violations of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied and Tronair disclaims any and all liability for injury (WITHOUT LIMITATION and including DEATH), loss or damage arising from or relating to such misuse.

### 8.0 APPENDICES




Lavatory Service Parts List
When ordering replacement parts/kits, please specify model, serial number and color of your unit.





Lavatory Service Parts List
When ordering replacement parts/kits, please specify model, serial number and color of your unit.




Front Steering Axle - Enlarged View


Item	Part Number	Description	Qty
1	Z-1797-01	Sub-Assembly, Lavatory Service Unit	1
2	H-K-4916	Kit, Fillwell Replacement	1
4	K-1391	Kit, Dump Tank Replacement	1
5	HC-1137	Valve, Ball	1
6	K-3970	Kit, Pin Replacement	1
7	Z-5584-01	Weldment, Tongue	1
8	K-1212	Kit, Discharge Pump	1
9	K-1688	Kit, Lid Replacement	1
10	C-191	Tank, 15 gallon Fill	1
11	TF-1005*96.0	Hose, Fill 96" Long	
12	H-1426-05	Clamp, Hose	
13	K-1233	Kit, 3" Flange	
13	K-1210	Kit, 4" Flange	1
14	K-1036	Kit, Shorts Coupling	1
15	K-1702	Kit, Pump	1
16	K-3971	Kit, Lever	
17	K-1550	Kit, Wheel (Single)	
19	K-1253	Kit, Bearing/Seal	1
20	K-1255	Kit, Hub Replacement	1



# **Pump Assembly Component**



Item	Part Number	Description	
	WC-1053	Pump Assembly	
1	WC-1053-01	Inlet Flange	1
2	WC-1053-02	Outlet Flange	1
3	WC-1053-03	Button	2
4	WC-1053-04	Clevis Assembly; consists of:	
	WC-1053-05	Clevis Pin	
	WC-1053-06	Clevis Supports	
	WC-1053-07	Side Plates	
	WC-1053-08	Bushings A & B	
	WC-1053-09	O-Rings #111	
	WC-1053-10	SS Washers	2
	WC-1053-11	TH ¼ - 20 x 5/8	2






# **Pump Assembly Component**

Item	Part Number	Description	Qty
5	WC-1053-12	Body	1
6	WC-1053-13	Clamp Ring	1
8	WC-1053-14	Handle With Grip	1
11	WC-1053-15	Actuator Extension	1
12	WC-1053-16	Hardware Set; Consists of:	
	WC-1053-17	HH ¼ - 20 x 7/8 (Inlet/Outlet)	8
	WC-1053-18	HH ¼ - 20 x 1 (Clamp Ring)	6
	WC-1053-19	HN ¼ - 20	14
	WC-1053-20	HH 5/16 – 18 x 1 ¼ (Actuator)	2
	WC-1053-21	HN 5/16 – 18 (Actuator)	2
	WC-1053-22	HH 3/8 – 16 x 2 (Actuator)	1
	WC-1053-23	HN 3/8 – 16 (Actuator)	1
13	WC-1053-24	Diaphragm	1
14	WC-1053-25	Flapper Valves	2



## **Discharge Pump Assembly Component**



Item	Part Number	Description	Qty
	WC-1054	Pump Assembly	REF
1	WC-1054-01	Inlet Flange	1
2	WC-1054-02	Outlet Flange	1
3	WC-1054-03	Button	2
4	WC-1054-04	Clevis Assembly; consists of:	
	WC-1054-05	Clevis Pin	1
	WC-1054-06	Clevis Supports	2
	WC-1054-07	Side Plates	2
	WC-1054-08	Bushings A & B	2
	WC-1054-09	O-Rings #111	2
	WC-1054-10	-10 SS Washers	
	WC-1054-11	TH ¼ - 20 x 5/8	2






# **Discharge Pump Assembly Component**

Item	Part Number	Description	Qty
5	WC-1054-12	Body	1
6	WC-1054-13	Clamp Ring	1
8	WC-1054-14	Handle With Grip	1
11	WC-1054-15	Actuator Extension	1
12	WC-1054-16	Hardware Set; Consists of:	
	WC-1054-17	HH ¼ - 20 x 7/8 (Inlet/Outlet)	8
	WC-1054-18	H ¼ - 20 x 1 (Clamp Ring)	
	WC-1054-19	HN ¼ - 20	
	WC-1054-20	HH 5/16 – 18 x 1 ¼ (Actuator)	
	WC-1054-21	HN 5/16 – 18 (Actuator)	2
	WC-1054-22	HH 3/8 – 16 x 2 (Actuator)	
	WC-1054-23	HN 3/8 – 16 (Actuator)	
13	WC-1054-24	Diaphragm	1
14	WC-1054-25	Flapper Valves	2







Item	Part Number	Description	Qty
1	N-1040-13	Elbow, ¾ NPT to ¾ Hose	
2	N-1500	Tee, ¾ NPT	1
3	N-1039-15	Connector, ¾ NPT to ¾ Hose	1
4	TF-1009-03*11.0	Hose, ¾ x 11 LG	1
5	N-2412-21	Connector, ¾ NPT to ¾ Hose	1
6	G-1250-1050N	Flatwasher, ¼ Narrow	4
7	G-1202-1050	ESN, ¼ - 20	4
8	H-1426-02	Clamp, Hose	11
9	TF-1009-03*03.5	Hose, ¾ x 3 ½ LG	1
10	WC-1053	Pump, LSU Fill	1
11	N-1501	Connector, ¾ to ¾ NPT	1
12	N-1508-06	Elbow, ¾ NPT to 1 Hose	1
13	TF-1005*18.0	Hose, 1 x 18 LG	1
14	H-1426-05	Clamp, Hose	2
15	HC-1137	Ball Valve, ½ NPT, Brass	1
16	G-1009-07	U-Bolt, ¼ - 20	2






# **LSU Pump**

Item	Part Number	Description	Qty
17	N-2410-09	Elbow, ½ PT to ¾ Hose	2
18	N-2412-23	Connector, ¾ NPT to 1 Hose	2
19	N-1514-06	Reducer, 1 1/4 to 3/4 NPT	2
20	N-1513-05	Elbow, ¾ Hose	1
21	TF-1009-03*03.0	Hose, ¾ x 3 LG	2
22	TF-1009-03*05.0	Hose, ¾ x 5 LG	1
23	N-1047-07	Tee, ¾ Hose	1
24	TF-1009-03*44.0	Hose, 3/4 x 44 LG	Ref

Model: 10D4036-0010 **Lavatory Service Unit** 



Discharge Pump Plumbing Parts List When ordering replacement parts/kits, please specify model, serial number and color of your unit.



Item	Part Number	Description	Qty
1	H-1201	Сар	1
2	H-1426-09	Clamp, Hose, 2 inch	6
3	TF-1018-02*120	Hose, Discharge, 10 ft. long	1
4	N-1502	Elbow	1
5	TF-1006*04.5	Hose, 4½" long	1
6	K-4285	Kit, Discharge Pump WC-1054	1
7	TF-1018-02*21.0	Hose, 2" I.D.	
8	G-1100-105010	Bolt, Hex Head, Grade 5, 1/4-20 x 1" long	4
9	G-1202-1050	Stopnut, ¼-20 Elastic	4
10	G-1250-1050N	Flatwasher, ¼ Narrow	4
11	Z-1794	Weldment, Frame	REF
12	N-1505	Adapter, Male	2
13	K-1209	Kit, Dump Tank	1

NOTES: 1. Kits contain all hardware necessary for installation.
2. Unless otherwise stated, all replacement bolts should be Grade 5 or better.



# **APPENDIX II**

**Declaration of Conformity** 



# **DECLARATION of CONFORMITY**

The design, development and manufacture is in accordance with European Community guidelines

Electric Lavatory Service Unit 10d4036-0010

Relevant provisions complied with by the machinery: 2006/42/EC

Relevant standards complied with by the machinery: EN ISO 12100-1

Identification of person empowered to sign on behalf of the Manufacturer:

Quality Assurance Representative

Phone: (419) 866-6301 | 800-426-6301

Web: www.tronair.com

Email: sales@tronair.com