Phone: (419) 866-6301 | 800-426-6301

Web: www.tronair.com

Email: sales@tronair.com



Model: K-2116 - PT6 Engine Support

This product can not be modified without the written approval of Tronair, Inc. Any modifications done without written approval voids all warranties and releases Tronair, Inc., its suppliers, distributors, employees, or financial institutions from any liability from consequences that may occur. Only Tronair OEM replacement parts shall be used.

1.0 DESCRIPTION

This PT6 Support Kit is to be used with 08-2001-0000 engine stand base and 08-0102-4010 engine sling.

The engine stand base has five (5) locations for mounting various supports and the upright post assembly. These positions are listed as "A through E" reference *Figure 2* (Page 3) engine stand assembly locations.

2.0 ENGINE SUPPORT INSTALLATION INSTRUCTIONS

- 1. Attach the upright post assembly to the base at base position "E" with ½-20 x 1 ¾" long hex head bolts, washers and elastic stopnuts, reference *Figure 2* engine stand (assembled).
- 2. Attach engine support to the base at base position "C" with 3/8-24 x 1 3/4" long bolts, bevel, washers, flatwashers and elastic stopnuts, reference *Figure 2* engine stand (assembled).
- 3. Assure that all nuts and bolts are secure before placing an engine in the stand.

3.0 ENGINE INSTALLATION INSTRUCTIONS

- 1. With the engine hung from the 08-0102-4010 engine sling, remove the existing lower airframe engine mount from the engine.
- 2. Lower the engine into the engine stand and align engine stand mounts with engine mounting pads.
- 3. Attach engine sling to the upright post assembly with 3/8-24 x 3 ½" long hex head bolts, washers and elastic stopnuts.
- 4. The engine installation is now complete.
- 5. To remove engine, reverse the above process.

4.0 GUARANTEES/LIMITATION OF LIABILITY

Tronair products are warranted to be free of manufacturing or material defects for a period of one year after shipment to the original customer. This is solely limited to the repair or replacement of defective components. This warranty does not cover the following items:

- a) Parts required for normal maintenance
- b) Parts covered by a component manufacturers warranty
- c) Replacement parts have a 90-day warranty from date of shipment

If you have a problem that may require service, contact Tronair immediately. Do not attempt to repair or disassemble a product without first contacting Tronair, any action may affect warranty coverage. When you contact Tronair be prepared to provide the following information:


- a) Product Model Number
- b) Product Serial Number
- c) Description of the problem

If warranty coverage is approved, either replacement parts will be sent or the product will have to be returned to Tronair for repairs. If the product is to be returned, a Return Material Authorization (RMA) number will be issued for reference purposes on any shipping documents. Failure to obtain a RMA in advance of returning an item will result in a service fee. A decision on the extent of warranty coverage on returned products is reserved pending inspection at Tronair. Any shipments to Tronair must be shipped freight prepaid. Freight costs on shipments to customers will be paid by Tronair on any warranty claims only. Any unauthorized modification of the Tronair products or use of the Tronair products in violation of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied.

The obligations of Tronair expressly stated herein are in lieu of all other warranties or conditions expressed or implied. Any unauthorized modification of the Tronair products or use of the Tronair products in violations of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied and Tronair disclaims any and all liability for injury (WITHOUT LIMITATION and including DEATH), loss or damage arising from or relating to such misuse.



Parts List - Figure 1
When ordering replacement parts/kits, please specify model, serial number and color of your unit.




Item	Part Number	Description	Qty
1	G-1420-107516	H. H. Bolt GR 8 3/8-24 x 1 3/4" long	
2	G-1250-1070N	Flatwasher, 3/8	
3	G-1202-1075	Elastic Stopnut 3/8-24	
5	Z-3710-01	Weldment, Engine Support	
6	G-1278	Washer, Modified Bevel	2
	K-1859	Kit, Engine Mounting Bracket:	
1		H. H. Bolt GR 8 3/8-24 x 1 3/4" long	
2		Flatwasher, 3/8	4
3		Elastic Stopnut 3/8-24	2
4		Weldment, Engine Mounting Bracket	1

Phone: (419) 866-6301 | 800-426-6301 Web: www.tronair.com Email: sales@tronair.com



Parts List - Figure 2 When ordering replacement parts/kits, please specify model, serial number and color of your unit.



Item	Part Number	Description	Qty
1	08-0102-4010	Engine Sling	Ref.
2	K-2116	Engine Support	1
3	08-2001-0000	Engine Stand	Ref.

Phone: (419) 866-6301 | 800-426-6301 Web: www.tronair.com

Email: sales@tronair.com



The Tronair Family of Ground Support Equipment and cloud based EBis GSE Fleet Management



The premier global supplier of ground support equipment



The Tronair Family of GSE Product Lines

UNPARALLELED RANGE OF PRODUCTS FOR BUSINESS, COMMERCIAL AND MILITARY AIRCRAFT

LIFTING & SHORING (ATA-7)

Hydraulic Tripod Jacks Axle Jacks Jack Test Equipment Stabilizing Stands & Alarms Aircraft Recovery Dollies

LEVELING & WEIGHING (ATA-8)

Aircraft Weigh Equipment

TOWING AND TAXIING (ATA-9)

Towbar Systems
Tow Vehicles & Tractors

PARKING & MOORING (ATA-10)

Chocks & Covers

SERVICING (ATA-12)

Multi-Purpose Carts
Hydraulic & Engine Oil Servicing
& Test Equipment
Lavatory Servicing Carts
Potable Water Transport Carts
Oxygen & Nitrogen Carts
Oxygen & Nitrogen Boosters

AIR CONDITIONING (ATA-21)

Air Conditioning Equipment Coolant System Fill/Drain Carts Cabin Pressurization Test Units

ELECTRICAL (ATA-24)

Ground Power Units
Battery Charger/Analyzer

FUEL (ATA-28)

Fuel Transfer Cart Fuel Tools

HYDRAULIC POWER (ATA-29)

Hydraulic Power Units Ram Air Turbine (RAT) Hydraulic Coupling Hose Adaptors

ICE & RAIN PROTECTION (ATA-30)

Deicer Carts

AIRCRAFT TOOLING

Designed to your Specifications

LANDING GEAR (ATA-32)

Beadbreakers
Dollies - Wheel & Brake
Service Tools
Strut Service Carts
Regulators, Adaptors,
Connectors & Gauges

FUSELAGE (ATA-53)

Lifts, Cranes & Hoists Maintenance Platforms Access Stands Docking Systems

PROPELLERS (ATA-61)

Propeller Stands/Slings/Tools

POWER PLANT (ATA-71)

Engine Compressor Washers Engine Hoists, Slings & Stands

CLOUD BASED FLEET MGT.

Manage your Repair Station, Multi Location Jet Center or Small Operation



www.columbusjack.com | www.daeind.com | www.datcomedia.com | www.eagletugs.com | www.malabar.com

Sales Offices: USA • Asia/China • Australia/New Zealand/Singapore • Europe/Middle East/Africa

Tronair, Inc. • 1 Air Cargo Pkwy East • Swanton, OH 43558, USA Phone: 419-866-6301 | Toll Free: 1-800-426-6301 | Email: sales@tronair.com