THIS DRAWING IS THE PROPERTY OF TRONAIR, INC. IT IS FURNISHED TO YOU FOR CONFIDENTIAL INFORMATION PURPOSES ONLY AND IS NOT TO BE DISCLOSED. TO ANYONE ELSE OR REPRODUCED OR USED FOR MANUFACTURING PURPOSES WITHOUT THE EXPRESS WRITTEN PERMISSION OF TRONAIR, INC.

(3.50)

## **CAUTION:**

- 1. NEVER put hands between aircraft and jack pad, as after aircraft has been lowered. struts may have hung up.
- 2. ALWAYS lower ram locking nut(s) after jack is under load. Be sure ram nut(s) is seated fully after jacking.
- 3. ALWAYS raise and lower jacks simultaneously so that aircraft reamins level.
- 4. ALWAYS use a tail or nose stand, as applicable, for additional stability.

#### **JACK INSTRUCTIONS**

#### TO RAISE AIRCRAFT:

- 1. Place iack on a hard surface.
- 2. Raise mechanical extension as close to aircraft jack pad as possible.
- 3. Open reservoir air vent as required.
- 4. Close pump release valve and operate pump.
- 5. Lower ram locknuts as aircraft is raised.

### TO LOWER AIRCRAFT:

- 1. Lower all jacks simultaneously.
- 2. If ram locking nut(s) is tight, raise jack slightly to release nut(s).
- 3. Loosen pump release valve slightly to slowly lower aircraft. Raise locking nut(s), as jack ram(s) lower.

5.60 )

V-1015

LET REVISION DWN DATE ΕC CHK Α 2290 SZS RMS 04-26-89 REDRAWN ADD ITEM #3 3607 MKNJMW 10-16-89 CHANGE LABEL DATE C1: ADDED H14ADH 15251 JDW JDW 08-14-06 C2: ADDED NOTE CHANGED SPECIFICATIONS; 15801 JRD WMW 07-30-07 REMOVED DATE CODE



# LABEL SPECIFICATIONS

SIZE: 3.5" L X 5.6" W

COLORS: TRONAIR BLUE: (CMYK 92/59/9/1)

(RGB 0/103/166)

(PMS 301)

BASE MATERIAL: .002 WHITE MYLAR

BORDER THICKNESS = 1/16"

LETTER WEIGHT = MEDIUM

PERMANENT PRESSURE SENSITIVE ADHESIVE:

WITH #14 ADHESIVE.

COATING: .001 CLEAR MYLAR OVERLAMINATION

SQUARE CUT | X ROLL DIE CUT

**BACKSPLIT** 

OTHER: V-NUMBER 1/16" LETTERS

NOTE: LABEL APPLIED TO POLYETHYLENE

MATERIAL.

MAKE FROM:			BF
PURCHASED			T (
MATERIAL: TYPE:			
SEE SPECIFICATIONS N/A			
FINISH:			
MILL			
THIRD ANGLE	$\bigoplus$	SIZE	
PROJECTION			
SCALE: <b>1:1</b>	DO NOT SCALE DRAWING	ב	



± .100 . X X ± .030 . X X X ± .010 FRACTION X/XX ± 1/16 ANGLES: ± 1/2 DEGREE

< > INDICATES CRITICAL DIMENSIONS ( ) INDICATES REFERENCE DIMENSIONS

AIRCRAFT GROUND SUPPORT EQUIPMENT DWN BY CKD BY SZS DSL 04-26-89

LABEL, JACKING INSTRUCTIONS

80 V-1015 D